

MA202-1A-AC / MA302-1A-AC*OP377-V01***Programming Scheme**

- **MA202-1A-AC / MA302-1A-AC** : via rear key (Tact Switch)

Sr.No.	Function	Method	Display Indication
1	To enter programming mode.	Press switch for 5 sec.	Ctr
2	CT Primary Setting (Default : 1A)	With every press of the key	1, 5, 10, 15, 20, 25, 30, 40, 50, 60, 75, 80, 100, 125, 150, 175, 200, 250, 300, 400, 500, 600, 630, 750, 800, 1000, 1200, 1500, 1600, 2000, 2250, 3000, 3200, 4000, 5000
3	To exit programming mode	Auto exit : 100sec. or switch OFF the unit & then switch it ON.	—